

# OZTENT

## RIVERGUM SELF INFLATING MATTRESS

**The Rivergum Self Inflating Mattress's excellent insulation is a result of combining open cell foam, air-tight vinyl, and velour backing.**

The features that make your Rivergum Mattress unique includes:

- Superior comfort that helps you rest and replenish.
- Insulation loss prevention with CFC-FREE, extra thick open-cell foam.
- Slip resistance with our air-proof and waterproof non-slip fabric.
- Automatic rapid inflation.
- Pliable foam core won't become brittle or stiff in extremely low temperatures.
- 12cm thickness for extra comfort.
- Unique construction which means you don't have welded seams on the corners (a potential weak spot in some brands of mattress).

### INFLATING YOUR MAT

1. Open valves.
2. The mattress will inflate automatically by drawing air through the valve.
4. Close valves once mattress has inflated.
5. Place in a location free from sharp objects.

**Pro Tip:** for the first inflation place the mat in the sunlight with the valves open this will allow the foam to decompress quicker.

### DEFLATING YOUR MATTRESS

1. Open valves.
2. Roll the mattress in the direction of the valve forcing the air out.
4. Close valves.
5. Now you can carry your compactly rolled mattress in it's carry bag.

**Pro Tip:** Start rolling the mattress up slowly. Press the remaining air out with your knees at every turn. In order to achieve an extra compact roll, it may be necessary to re-roll the mattress 2 or 3 times.

### USE IN EXTREMELY LOW TEMPERATURES

If temperatures are very low, your self inflating mattress may inflate slower than usual.

### NEVER BLOW AIR TO INFLATE THE MATTRESS

Your breath contains moisture which may condense inside the mattress or around the valve, impeding future use.

### TRANSPORTATION

When transporting your mattress, keep it free from sharp or pointy objects, and from abrasion. Always use the carry bag supplied with the mattress.

### HEAT

Never expose the mattress to great heat over long periods.

### STORAGE

If you do not plan on using your mattress for an extended period of time, open the valve and store your mattress unrolled in a dry place, such as a wardrobe or under the bed. If the mattress remains moist for too long, it is possible that mould could destroy the cover and the insides.

### CLEANING

1. Ensure that the valves are closed.
2. Clean your mattress with mild soap suds and/or with a soft brush. Do not rub the velour surface too hard as this will remove the coating.
3. Rinse off well and leave to dry in a cool dry place out of direct sun light.

### WARNING

Keep your mattress away from naked flames and sparks. Never store your mattress in places which are overheated and exposed to direct sunlight such as on the seat or in the boot of the car. Defects resulting from improper storage are not covered by warranty. Ultraviolet radiation and solvents can damage your mattress. On account of this your mattress should be exposed as little as possible to ultraviolet radiation and never sprayed with insecticides or disinfectants.

### REPAIRS

Patching your mattress is made very easy with our repair kit.

1. To find leaks, firstly inflate your mattress and close the valves. Lay on the mattress and listen for the air escaping. If necessary, lightly spray areas of the mattress with a soapy solution and watch where bubbles form.
2. Mark these and let your mat dry.
3. Open valves.

In the case of small punctures (prick points):

1. Place one or two drops of glue onto the leaks.
2. Let these dry for at least 1 hour before using the mattress.
- 3.

# OZTENT

## RIVERGUM SELF INFLATING MATTRESS

In the case of larger punctures:

1. Spread the glue thinly with a circular motion on to the dry, clean, and lightly roughened surface of the mattress. ( If patching the velour side of the mattress, remove as much of the velour as possible by firmly rubbing with a wet finger).
2. Remove the protective paper from the patch and spread a thin layer of glue onto the back of the patch.
3. After the glue has dried (about 3 minutes), position the patch on the mattress and press down stroking lightly from the centre and outwards. Avoid forming blisters and creases.
4. Afterwards press down firmly and leave to dry for at least 60 minutes (if the tear exceeds 1cm in length, leave for 120 minutes).
5. Leave for 24 hours for best results. In humid or below 5c temperatures, drying may take twice as long.

### **GLUE WARNING**

- Glue is highly flammable! Do not use in proximity of naked flames, sparks, or heat sources.
- Glue can damage your health. Only use in well ventilated areas. Avoid inhaling fumes and skin contact.

### **FIRST AID**

In the event of glue coming into contact with your eyes, rinse with plenty of water for at least 10 minutes. Seek medical attention immediately. Keep out of reach of children!